



How to properly place a Requisition into a Bio-Bag with a liquid Pap-Prep

1.




Place Req next to Pap-Prep & Bio-Bag.

2.




Fold Req in Half, bottom under, so that Pt. name is on Top.

3.



Fold Req in Half again, right side under so that Pt. name is on Top.

4.



Insert the folded Req into the Pap-Prep & Bio-Bag so that the Pt. Name is clearly visible from the Back of the Bio-Bag.

5.



Make sure top of the Bio-Bag is Sealed.

6.



Back side of the Req shows on the Warning side of the Bio-Bag.

Note that one side of the Bio-Bag has various Text and Warning Images...

The Patient information SHOULD NOT face the Warning side of the Bio-Bag!

The availability to easily read and process these specimens will increase productivity and reduce the amount of errors in the order entry process.

Thank you for your cooperation ☺